

# Glove box system

Manufacturing in inert gas to avoid damage caused by oxygen and moisture

## MBraun 200 B glove box

- Filled with nitrogen
- Oxygen < 1 ppm
- Humidity < 1 ppm
  
- Two separate glove boxes, one for dry and one for wet processes

